

# How to Use the Projector Settings Window

---

**Video description:** This video shows you how to use the projector settings window. This allows you to change the settings of a specific piece of hardware. This includes size, scanrate limits (minimum and maximum speed), color settings (TTL/Analog), color shift, vector settings, blanking and anchors.

---

[Return to tutorial videos](#)

From:

<https://wiki.pangolin.com/> - Complete Help Docs

Permanent link:

[https://wiki.pangolin.com/doku.php?id=quickshow:video:quickshow\\_quickhints\\_projector\\_settings\\_window&rev=1678182250](https://wiki.pangolin.com/doku.php?id=quickshow:video:quickshow_quickhints_projector_settings_window&rev=1678182250)

Last update: **2023/03/07 10:44**

