

# Akai APC Mini Layout V1

**PANGOLIN LASER SYSTEMS** APCmini

**Cue Grid**

**Zone toggle**

- CLIP (SCENE LAUNCH)
- SOLO
- MUTE
- SEARCH (SOFT RECALL)
- RESET ROTATIONS
- RESET MASTER / CUE
- LIVE TO MASTER / CUE
- BPM TAP
- SHIFT

Color, Brightness, Rotation X Delta, Rotation Y Delta, Rotation Z Delta, Size XY, Visible points, Scan speed, Animation speed

**AKAI PROFESSIONALS** APCmini

**FX Grid**

- CLIP (SCENE LAUNCH)
- SOLO
- MUTE
- SEARCH (SOFT RECALL)
- RESET ROTATIONS
- RESET MASTER / CUE
- LIVE TO MASTER / CUE
- BPM TAP
- SHIFT

Pause, Next category, Previous category, Virtual LJ Toggle, Set BPM 120, While holding shift

*Lasershow Designer QuickShow*

WWW.PANGOLIN.COM

From:

<http://wiki.pangolin.com/> - **Complete Help Docs**

Permanent link:

<http://wiki.pangolin.com/doku.php?id=beyond:akaiapc40mini&rev=1568056331>

Last update: **2020/06/11 19:23**

