

Live Control tab -- Size controls

Using the Live Control tab, you can affect the **Size** of everything together (when in [Master mode](#)), or the size of individual cues (when in [Cue mode](#)). The picture below explains the various options.



When activated, forces the horizontal and vertical sliders to move at the same time

Automatic Zoom out and Zoom up

You can automatically zoom the image out by pressing the button on the left.

You can automatically zoom the image up by pressing the button on the right.

Right click

Note that if you click the right mouse button on a **Size** slider, its value will be reset to 100%.

See Also

- [Live Control tab](#)
- [Controlling cues during playback](#)

[Return to Index](#)

From:

<http://wiki.pangolin.com/> - **Complete Help Docs**

Permanent link:

http://wiki.pangolin.com/doku.php?id=quickshow:size_controls

Last update: **2020/06/11 19:20**

