

# Akai APC Mini Layout V1

**PANGOLIN LASER SYSTEMS** APCmini

Cue Grid

Zone toggle

- CLIP (Blackout)
- SOLO (Enable/Disable output)
- PREV (Next tab)
- NEXT (Previous tab)
- RESET (Reset rotatoins)
- MASTER (Reset master / cue)
- LIVE (Live to master / cue)
- BPM (BPM Tap)
- SHIFT (Shift)

Color, Brightness, Rotation X Delta, Rotation Y Delta, Rotation Z Delta, Size XY, Visible points, Scan speed, Animation speed

**AKAI PROFESSIONALS** APCmini

FX Grid

- Pause
- Next category
- Previous category
- Virtual LJ Toggle
- Set BPM 120
- While holding shift

Lasershow Designer QuickShow

WWW.PANGOLIN.COM

From:

<https://wiki.pangolin.com/> - **Complete Help Docs**

Permanent link:

<https://wiki.pangolin.com/doku.php?id=beyond:akaiapc40mini&rev=1568056331>

Last update: **2020/06/11 19:23**

