

APC Mini support

QuickShow 3.0 includes support for the tiny, USB/MIDI-based console called the APC Mini made by Akai.

Unlike other MIDI devices used by QuickShow, the APC Mini will be detected when QuickShow starts, with no intervention or configuration needed by the user. Simply plug it in and start QuickShow.


Button and slider mapping

Below you will see a few pictures that illustrate how the APC Mini buttons and sliders are “mapped” to the QuickShow user interface.

PANGOLIN LASER SYSTEMS

APCmini

Cue Grid




Zone toggle



Color
Brightness
Rotation X Delta
Rotation Y Delta
Rotation Z Delta
Size XY
Visible points
Scan speed
Animation speed

- CLIP STOP: Blackout
- SOLO: Enable/Disable output
- REC ARM: Next tab
- MUTE: Previous tab
- SELECT SOFT KEYS: Reset rotations
- RESET: Reset master / cue
- LIVE TO MASTER: Live to master / cue
- BPM TAP: BPM Tap
- SHIFT: Shift

FX Grid



- CLIP STOP: Pause
- SOLO: Next category
- MUTE: Previous category
- SELECT SOFT KEYS: Virtual LJ Toggle
- RESET: Set BPM 120
- SHIFT: While holding shift

Lasershow Designer QuickShow

WWW.PANGOLIN.COM

See Also

- [MIDI Settings](#)

[Return to index](#)

From:

<https://wiki.pangolin.com/> - **Complete Help Docs**

Permanent link:

<https://wiki.pangolin.com/doku.php?id=quickshow:apcmini&rev=1564422318>

Last update: **2020/06/11 19:21**

