


Editing controls: Laser Preview window

The Laser Preview window is found at the top of the [Editing Controls area](#), just below the [Information panel](#). The Laser Preview window allows you to preview the laser frames, and also provides additional information.



The Laser Preview window allows you to see the current frame (selected by the [Frame slider](#)) in the Lasershow Designer frame list. As you move the [Frame slider](#), you will see this frame change.

See Also

- [Frame Slider](#)

From:
<https://wiki.pangolin.com/> - **Complete Help Docs**

Permanent link:
https://wiki.pangolin.com/doku.php?id=tools:lcflash:laser_preview

Last update: **2021/04/23 13:23**

