
APC Mini MKII support

QuickShow 5.2 includes support for the USB/MIDI-based console called the APC Mini MK2 made by Akai.

Unlike other MIDI devices used by QuickShow, the APC Mini MKII will be detected when QuickShow starts, with no intervention or configuration needed by the user. Simply plug it in and start QuickShow.

Button and slider mapping

Below you will see a few pictures that illustrate how the APC Mini MKII buttons and sliders are “mapped” to the QuickShow user interface.


PANGOLIN LASER SYSTEMS
APCmini
Cue Grid
Zone toggle
Blackout
Enable/Disable output
Next tab
Previous tab
Reset rotatoins
Reset master / cue
Live to master / cue
BPM Tap
Shift
Color
Brightness
Rotation X Delta
Rotation Y Delta
Rotation Z Delta
Size XY
Visible points
Scan speed
Animation speed
AKAI PROFESSIONAL
APCmini
FX Grid
Pause
Next category
Previous category
Vitual LJ Toggle
Set BPM 120
While holding shift
Lasershow Designer
QuickShow
WWW.PANGOLIN.COM

See Also

- MIDI Settings

Return to index

From:
https://wiki.pangolin.com/ - **Complete Help Docs**

Permanent link:
https://wiki.pangolin.com/doku.php?id=quickshow:apcmini_mkii

Last update: **2023/01/20 20:38**