

APC Mini support

QuickShow 3.0 includes support for the tiny, USB/MIDI-based console called the APC Mini made by Akai.


Unlike other MIDI devices used by QuickShow, the APC Mini will be detected when QuickShow starts, with no intervention or configuration needed by the user. Simply plug it in and start QuickShow.

Button and slider mapping

Below you will see a few pictures that illustrate how the APC Mini buttons and sliders are “mapped” to the QuickShow user interface.

PANGOLIN LASER SYSTEMS

Cue Grid



FX Grid

**Lasershows
Designer****QuickShow**WWW.PANGOLIN.COM

- Blackout
- Enable/Disable output
- Next tab
- Previous tab
- Reset rotatoins
- Reset master / cue
- Live to master / cue
- BPM Tap
- Shift

- Pause
- Next category
- Previous category
- Vitual LJ Toggle

- Set BPM 120
- While holding shift

See Also

- [MIDI Settings](#)

[Return to index](#)

From:

<https://wiki.pangolin.com/> - **Complete Help Docs**



Permanent link:

<https://wiki.pangolin.com/doku.php?id=quickshow:apcmini>

Last update: **2020/06/11 19:20**