

Toolbar overview

The main functions within QuickShow are controlled by the Toolbar which is located at the top of the Main Control Window. The toolbar is shown below.



Cue triggering mode

The Cue triggering mode controls what happens when you click on a cue with the mouse (or touch screen).



If the **Select** mode is chosen, cues are not activated when you click on them. Cues are only selected. This is handy when you want to drag and drop cues to a QuickTimeline, or when you want to change the Properties of a cue, without activating the cue.

If the **Toggle** mode is chosen (as indicated above with the green highlight), cues will “toggle” their activation mode each time you click on the cue. For example, if you click on a cue once, it will start playing. If you click on the cue again, it will stop playing. **Toggle** is the default cue triggering mode.

If the **Restart** mode is chosen, cues will be restarted each time you click on them. For example, if you have an animation which counts down to zero, the count-down will restart each time you click on the cue, if **Restart** mode is chosen.

If the **Flash** mode is chosen, cues will only remain active for the period of time you are clicking on them (or holding your finger pressed on the touch screen). For example, when you click the left mouse button on the cue, the cue will begin playing and will remain playing until you release the left mouse button.

Transition between cues

The **Transition** button controls what happens when you trigger a new cue and there is already a cue playing.



When **Transition** is activated, morphing will be performed between the currently-displayed output and the next cue you press.

You can change the type of transition that is performed by right-clicking on the Transition button. You can also control the transition by showing the Dynamics tab in the View menu.

Playing only One Cue at a time, or Multiple cues, or cue Groups

QuickShow allows you to play either one cue at a time, or multiple cues simultaneously, depending on whether the **One cue** or **Multi cue** button is pressed.



You can choose the behavior of both the **One Cue** button, and the **Multi cue** button, by right-clicking on each button. These can also be controlled by showing the Dynamics tab in the View menu.

Live Control

Effect

Dynamics

HOLD Cue limit

3

FLASH Cue limit

3

Per-Zone limit

3

Per-Grid limit

8

Beam Cue limit

3

DMX Cue Limit

3

Show Cue Limit

3

Cue appearance

Soft pause duration

Cue start

0.0

Cue finish

1.0

☒ Soft start/finish duration

Cue start

0.2

Σ

Cue finish

0.4

Σ

☐ Use Start effect in Flash mode
 ☒ Use Finish effect in Flash mode
 ☐ Use Start effect in Flash Solo mode
 ☐ Use Finish effect in Flash Solo mode

Transition

Zoom In

Fade In

Cross fade

Morphing

Cross Cut

Scroll Left

Scroll right

Scroll top

Scroll bottom

Trim left

Trim right

Trim top

Duration

0.3

⚠

🕒

Also from Quick Show 4.0 Pangolin offers a new way to perform live shows. The idea is simple – you can [Group Cues](#) together to make it easier for you to find Cues of certain types or with certain properties eg. Beat Reactive Cues, Time Based Cues, or types eg. Liquid Skies, Strobing Cues, Fast Cues, Slow Cues etc.

Beat synchronization system

QuickShow is a beat-oriented program. The beat counter is always running and you can see the beats per minute, and also a metronome icon to indicate the beat of the music.



You can set the beat by repeatedly clicking on the “BPM” label, or by repeatedly tapping the **SPACE BAR** on the computer keyboard. You must click the BPM label or press the **SPACE BAR** repeatedly to the beat of the music. When you do this, the average BPM of the clicks or key presses will be calculated and this will be used to synchronize the timer beat system.

Note that you can press the **BACKSPACE** key on the computer keyboard to “re-synchronize” the timer beat system to the beat of the music, in case the music timing becomes slightly ahead or behind the timer.

You can also enter a specific BPM, and control other aspects of beats by right-clicking on the Beat icon.

Virtual Laser Jockey button

QuickShow includes a new and ground breaking feature called [Virtual Laser Jockey](#), which can be used to make a completely automated laser show synchronized to the BPM or incoming audio.



Blackout and Pause

The Blackout and Pause buttons control the overall playback of QuickShow




The **Blackout** button causes all output to immediately stop. This will also reset certain program functions, including the cue triggering mode. **Blackout** can also be activated by pressing the **ESC** key on the computer keyboard.

The **Pause** button will pause all currently-playing cues. **Pause** can also be activated by pressing the **Pause** key on the computer keyboard.

Enabling laser output

The **Enable Laser Output** button is found at the far right of the toolbar.



In order to enable output from the FB3 laser controller, the **Enable Laser Output** button must be pressed.

See Also

- [Cue Grid](#)
- [Main Control Window](#)
- [Keyboard Equivalents](#)
- [Virtual Laser Jockey](#)

[Return to Index](#)

From:

<https://wiki.pangolin.com/> - **Complete Help Docs**

Permanent link:

<https://wiki.pangolin.com/doku.php?id=quickshow:overview>

Last update: **2020/06/11 19:20**

