DMX Settings

QuickShow may be setup to be controlled by an incoming DMX signal (DMX input), or to control external DMX devices such as lights and fog machines (DMX output). Both of these are specified using the DMX Settings dialog box, which is shown below.

DMX Settings ×						
General DMX Input settings						
Connection						
 Disable DMX Input and Output 						
Enable DMX Input						
C Enable DMX Output						
ENTTEC - DMX USB PRO						
Communication port						
COM7						
Information						
ENT TEC DMX USB PRO Controller detected. Serial number: "02144007" Firmware: 1.44						
ОК						
Lindate list Connect						
Update list Connect						
Commands: 2 OK Cancel						

First specify whether you want to use DMX Input or Output using the "Connection" portion of the dialog box. After that, specify the COM port where the DMX-to-USB controller is connected.

QuickShow gives you the ability to test the connection of the USB device by pressing the **Connection** button. If you have the proper COM port selected and the device is connected and working properly, it should give you a message box which will show the serial number and firmware version installed in the device as shown above.

DMX Input

If you want an external lighting console to be able to trigger QuickShow cues and control them live, choose the **Enable DMX Input** option. You will also need to specify the Starting DMX Channel (address) where you want QuickShow to appear within the DMX stream.

DMX Setti	ings	×						
General	DMX Input settings	_						
Starting	DMX Channel 1							
Channe	el Function							
1	Access	-						
2	Page	-						
3	Cue							
4	Speed							
5	Fade							
6	Zoom							
7	X Size							
8	Y Size							
9	Z Angle							
10	X Position							
11 12	Y Position Visble points							
13	Scan rate							
14	unused							
15	Color							
	00.01							
031 - Blackout 3296 - Basic Range (4 channels) 97160 - Standard Range (8 channels) 161224 - Extended Range (12 channels) 225255 - Full Range (16 channels)								
	OK Cancel							

As shown above, the DMX Channel Assignment for QuickShow is exactly the same as that of the FB3-SE DMX daughter board. This allows external controllers that are already familiar with the FB3 to easily control QuickShow in the same way and providing the same results.

DMX Output

If you want to control external devices such as beam tables, LEDs, lights or fog machines, choose the Enable DMX Output option. You will also need to specify the Number of channels that QuickShow should transmit. The default is 512 channels.

DMX Se	ettings				×			
General D	MX Output settings							
DMX Output settings								
Number	512	• •						
Break Delay					* *			
Mark-After-Break Break Delay					<u>+</u>			
Start code					÷			
Controller output rate (0-Auto)					* *			
Reset to defaults Apply DMX sequence processing								
Accumulate state for the next update								
Commands:	2		OK	Car	icel			

The DMX Output settings also has advanced controls that allow you to control the timing of the DMX signal. Generally the default values should work well, and you would only need to make adjustments to these settings if you suspect data corruption or incorrect DMX signal receipt.

DMX to USB device needed

Note that in order to use DMX for either input or output, you must first acquire a DMX to USB converter device. Currently QuickShow supports only the DMX USB PRO controller from the company ENTTEC. This is a very popular device which is freely available from many vendors on the internet. Pangolin also normally carries a limited stock of these devices as well.



DMX daughter board on FB3-SE can not be used

Also note that if you have a FB3-SE with a DMX daughter board installed, this can not be used for DMX input or output with QuickShow. The DMX daughter board on the FB3 is only used by the FB3 for direct FB3 control and playback.

See Also

• QuickDMX

Return to Index

From: https://wiki.pangolin.com/ - **Complete Help Docs**

Permanent link: https://wiki.pangolin.com/doku.php?id=quickshow:dmx settings

Last update: 2020/06/11 19:20

