

# BEYOND OSC

BEYOND offer control by means of OSC protocol. BEYOND act as server, what mean that it execute commands (messages) sent by OSC Client. There are many OSC Client applications for various platforms. Typically OSC Client application allow to create or adjust User Interface that will generate the messages. BEYOND will receive and execute the message. BEYOND has ready for use OSC Server that do not require any configuration or settings. You (client application) need to send the message corresponding address and corresponding arguments. Information about OSC messages is below.

## OSC Message

OSC Message contains 3 parts:

1. Ordered List ItemAddress. Address is a string and define what functionality the message will have.
2. Type Tag String. Type Tag String define the types of arguments that comes inside the message.
3. Argument(s). the value that comes with message.

As example, for control of master position. The address is `/beyond/master/livecontrol/position`. Together with the address the OSC Client must send 2 or 3 values - X, Y (optional Z) axis. As example, in TouchOSC you will need to enter the address and define the value range (min, max). The value and its type will be added automatically by TouchOSC.

## Supported Argument types

BEYOND support integer number (i), float point number (f), and string (s). Other data types ignored. You need to ensure that OSC client send correct type of argument to BEYOND.

Supported addressing schemes.

Characters: `, / [ ] { } * ? ! ' ' #` are used for address format and can not be used in names. These characters has special functionality:

- Pattern matching (from OSC specification)
- `'?'` in the OSC Address Pattern matches any single character
- `'*'` in the OSC Address Pattern matches any sequence of zero or more characters
- `[abcde]` - any of specified characters. In example - a,b,c,d,e
- `[ad-fx]` - `"-"` means a series of characters. In example: a,d,e,f,x
- `[!abc]` - `"!"` means inversion. in example we have `"all except a,b,c"`. In all other places `"!"` can not be used.
- `{aaa,bcd}` - means any of strings separated by comma. In example: aaa or bcd

Extended syntax when use OSC servers in PangoScript. (not relating to OSC clients such as TouchOSC, Lemur and so on)

It is possible to use OSC syntax in PangoScript. You type an address and arguments. Scripter will analyze and supply for execution into BEYOND OSC servers. You can use variables of script inside address. Variable name should be inside < >

### Example:

```
var MyVariable
MyVariable = 0
/beyond/zone/<MyVariable>/select 1
```

## Direct servers

This kind of server provide a direct access to internal object of BEYOND. No extra layers, or something in between. BEYOND receive the OSC packet, analyze the address and if the address point on direct server, the BEYOND execute it right after the address parsing. Such servers has fixed address part and number of arguments.

Server: DMX Input		
Address	Argument type(s)	Commentary
/beyond/dmx	fff..f	Gateway. array of f (floats) goes to DMX output. value 0..255. "-1" is special "undefined" state
Server: Beams		
Address	Argument type(s)	Commentary
/beyond/beams	fff..f	Gateway. Control beams. Works as brightness control per beam. 0 - off. 255 - on.
Server: Channels		
Address	Argument type(s)	Commentary
/beyond/channels	fff..f	Gateway. Control channels. Value range 0..1
Server: MULTI TOUCH interface		
Address	Argument type(s)	Commentary
/beyond/touch/x	f	value 0..1.
/beyond/touch/y	f	value 0..1.
/beyond/touch/z	f	value 0..1, means a pressure. 1 full pressure. 0 - off

## Live Control Parameters

There are a few areas where used Live Control object:

```
/beyond/master/...
/beyond/cue/...
/beyond/zone/...
/beyond/projector/...
/beyond/protrack/...
```

example of full path to Live Control:

```
/beyond/master/livecontrol/size
/beyond/cue/0/0/livecontrol/size
/beyond/zone/0/livecontrol/size
/beyond/projector/0/livecontrol/size
/beyond/spatial/0/livecontrol/size
/beyond/smart/0/livecontrol/size
```

## NOTE 1

```
/beyond/protrack/ - here can be used index or name of protrack-object
/beyond/zone/ - here can be used index or name of zone-object
```

In the table below a list of functions (ending name of the address):

Function	Type	Commentary
size	f	-400..400 - one size for all 3 axis
sizeX	f	-400..400
sizeY	f	-400..400
sizeZ	f	-400..400
zoom	f	0..100
posX	f	-32768 .. 32768 . Coordinate for output 16 bit
posY	f	-32768 .. 32768 . Coordinate for output 16 bit
posZ	f	-32768 .. 32768 . Coordinate for output 16 bit
angleX	f	-360*8 .. 360*8 . 8 rounds
angleY	f	-360*8 .. 360*8 . 8 rounds
angleZ	f	-360*8 .. 360*8 . 8 rounds
rotoX	f	-360*4 .. 360*4 . 4 rounds per second
rotoY	f	-360*4 .. 360*4 . 4 rounds per second
rotoZ	f	-360*4 .. 360*4 . 4 rounds per second
brightness	f	0..100
visiblepoints	f	0..100
colorslider	f	0..255
anispeed	f	0..400
scanrate	f	10..200. 100 default
red	f	0..255
green	f	0..255
blue	f	0..255
alpha	f	0..255
fx1	f	-1..47. -1 means stop. 0..47 - effect index. 48 effects per row
fx2	f	-1..47. -1 means stop. 0..47 - effect index. 48 effects per row
fx3	f	-1..47. -1 means stop. 0..47 - effect index. 48 effects per row
fx4	f	-1..47. -1 means stop. 0..47 - effect index. 48 effects per row

fx1action	f	0..100. effect action. 100 means fill action
fx2action	f	0..100. effect action. 100 means fill action
fx3action	f	0..100. effect action. 100 means fill action
fx4action	f	0..100. effect action. 100 means fill action
size	ff	size by x,y axis. -400..400
pos	ff	position by x,y axis. -32768 .. 32768
size	fff	size by x,y,z axis. -400..400
pos	fff	position by x,y,z axis. -32768 .. 32768
angle	fff	angle by x,y,z axis
roto	fff	rotation speed by x,y,z axis
fx	ffff	four FX indexes. -1 means stop. 0..47 - effect index. 48 effects per row

## Server: MASTER

/beyond/master/livecontrol/...

## Server: CUE

/beyond/cue/#/#/livecontrol/... require two indexes - page and cue

## Server: ZONE

Function	Type	Commentary
/beyond/zone/#/select	f	0-undelect. 1-select, 2-toggle state
/beyond/zone/#/mute	f	0-default, unmuted. 1-mute. 2-toggle state
/beyond/zone/#/livecontrol/...		

# is the index of the zone

## Server: PROJECTOR

Function	Type	Commentary
/beyond/projector/#/livecontrol/...		
/beyond/projector/#/sizex	f	-100..100
/beyond/projector/#/sizey	f	-100..100
/beyond/projector/#/posx	f	-100..100
/beyond/projector/#/posy	f	-100..100
/beyond/projector/#/swapxy	f	0-off, 1-on, 2-toggle
/beyond/projector/#/invx	f	0-off, 1-on, 2-toggle
/beyond/projector/#/invy	f	0-off, 1-on, 2-toggle

# is index of the spatial defined in UI

## Server: ProTrack

Function	Type	Commentary
/beyond/protrack/#/select	f	0-unselect. 1-select 2-toggle state
/beyond/protrack/#/mute	f	0-default, unmuted. 1-mute. 2-toggle state
/beyond/protrack/#/livecontrol/...		
/beyond/protrack/#/CODENAME	CODENAME	is a name of "daemon" script defined inside protrack object. Function "start" the scripter

# is index or NAME of the protrack object defined in Setup dialog

## Server: FIXTURE

/beyond/fixture/NAME/FUNCTION

"**NAME**" is index or NAME of the FIXTURE object defined in Setup dialog. "**FUNCTION**" is name of function that exists in the Fixture

## OSC to PangoScript GATEWAY

Server transform the OSC message to the command first and then the command goes to execution. The command appear in the system in the same way as it could be from the keyboard, or the mouse. This kind of servers also has fixed address and corresponding set of arguments. Actually, the address of such OSC server is a way to describe BEYOND command. And it was main intention - to give OSC the ability to do the same what the Script can do. Both parts (OSC and Script) produce a Command at the end, and why not to mix both worlds.

Address of message and number of arguments should correspond to the PangoScript command. Available following addressing:

```
/beyond/general/...
/beyond/master/...
/beyond/cue/...
/beyond/zone/...
/beyond/projector/...
/beyond/protrack/...
```

"general" use for variety of script commands. All others are for specific features of object, or for live control (see above)

The "general" serve contain embedded Scripter-object that always exists. Basically, you supply a command into embedded scripter and then it wait for the next command

Address	Type	Commentary
---------	------	------------

/beyond/general/CueDown	ii or iii	
/beyond/general/CueUp	ii or iii	
/beyond/general/PauseCue	iii	
/beyond/general/RestartCue	ii	
/beyond/general/StopAllNow	-	
/beyond/general/StopAllSync	f	
/beyond/general/StopAllAsync	f	
/beyond/general/StopCueNow	ii	
/beyond/general/StopCueSync	iif	
/beyond/general/StopZone	if	
/beyond/general/StopZonesOfProjector	i	
/beyond/general/BlackOut	-	
/beyond/general/EnableLaserOutput	-	
/beyond/general/DisableLaserOutput	-	
/beyond/general/MasterPause	i	
/beyond/general/VirtualLJ	i	
/beyond/general/VLJFX	ii	
/beyond/general/BeatTap	-	
/beyond/general/SetBpm	f	
/beyond/general/SetBpmDelta	f	
/beyond/general/BeatResync	-	
/beyond/general/OneCue	-	
/beyond/general/OnePer	-	
/beyond/general/MultiCue	-	
/beyond/general/Transition	i	
/beyond/general/ClickSelect	-	
/beyond/general/ClickToggle	-	
/beyond/general/ClickRestart	-	
/beyond/general/ClickFlash	-	
/beyond/general/ClickSoloFlash	-	
/beyond/general/ClickLive	-	
/beyond/general/TimerBeat	-	
/beyond/general/AudioBeat	-	
/beyond/general/ManualBeat	-	
/beyond/general/ClickScrollZoom	f	
/beyond/general/ClickScrollSize	f	
/beyond/general/ClickScrollFade	f	
/beyond/general/ClickScrollVPoints	f	
/beyond/general/ClickScrollScanRate	f	
/beyond/general/ClickScrollColor	f	
/beyond/general/ClickScrollAniSpeed	f	
/beyond/general/ClickScrollIR	f	
/beyond/general/ClickScrollIG	f	

/beyond/general/ClickScrollB	f	
/beyond/general/ClickScrollA	f	
/beyond/general/SetLimiterProfile	i	
/beyond/general/SetLimiterPerZone	i	
/beyond/general/SetLimiterPerGrid	i	
/beyond/general/SetLimiterFlash	i	
/beyond/general/SetLimiterHold	i	
/beyond/general/SetLimiterBeam	i	
/beyond/general/SetLimiterDMX	i	
/beyond/general/SetLimiterShow	i	
/beyond/general/MasterTransitionIndex	i	
/beyond/general/MasterTransitionTime	f	
/beyond/general/MasterTransition	i	
/beyond/general/DisplayPopup	ANY TTS	
/beyond/general/DisplayPreview	si	
/beyond/general/MasterSpeed	f	
/beyond/general/UnselectAllSmart	-	
/beyond/general/SelectSmart	ANY TTS	
/beyond/general/UnselectSmart	ANY TTS	
/beyond/general/ToggleSelectSmart	ANY TTS	
/beyond/general/UnmuteAllSmart	-	
/beyond/general/MuteSmart	ANY TTS	
/beyond/general/UnmuteSmart	ANY TTS	
/beyond/general/ToggleMuteSmart	ANY TTS	
/beyond/general/UnselectAllFixt	-	
/beyond/general/SelectFixt	ANY TTS	
/beyond/general/UnselectFixt	ANY TTS	
/beyond/general/ToggleSelectFixt	ANY TTS	
/beyond/general/UnmuteAllZone	-	
/beyond/general/MuteZone	ANY TTS	
/beyond/general/UnmuteZone	ANY TTS	
/beyond/general/ToggleMuteZone	ANY TTS	
/beyond/general/MuteSelected	i	
/beyond/general/UnselectAllZones	-	
/beyond/general/SelectZone	ANY TTS	
/beyond/general/SelectZoneName	ANY TTS	
/beyond/general/UnselectZone	ANY TTS	
/beyond/general/UnselectZoneName	ANY TTS	
/beyond/general/ToggleSelectZone	ANY TTS	
/beyond/general/ToggleSelectZoneName	ANY TTS	
/beyond/general/MuteSelectedZones	i	
/beyond/general/SetGridSize	ii	
/beyond/general/MasterPauseTime	i	

/beyond/general/StoreZoneSelection	-	
/beyond/general/ReStoreZoneSelection	-	
/beyond/general/SelectGrid	i	
/beyond/general/SelectTabName	s	
/beyond/general/SelectTab	i	
/beyond/general/SelectNextTab	-	
/beyond/general/SelectPrevTab	-	
/beyond/general/SelectPageName	-	
/beyond/general/SelectPage	i	
/beyond/general/SelectNextPage	-	
/beyond/general/SelectPrevPage	-	
/beyond/general/SelectAllCat	-	
/beyond/general/SelectCatName	s	
/beyond/general/SelectCat	i	
/beyond/general/SelectNextCat	-	
/beyond/general/SelectPrevCat	-	
/beyond/general/FocusCell	ii	
/beyond/general/FocusCellIndex	i	
/beyond/general/StartCell	-	
/beyond/general/ReStartCell	-	
/beyond/general/StopCell	-	
/beyond/general/ShiftFocus	i	
/beyond/general/MoveFocus	ii	
/beyond/general/SelectCue	s	
/beyond/general/StartCue	s	
/beyond/general/StopCue	s	
/beyond/general/LoadCue	s	
/beyond/general/LoadWorkspace	s	
/beyond/general/SetPage	i	
/beyond/general/GetPage	-	
/beyond/general/SelectMidi	i	
/beyond/general/MidiOut	iii	
/beyond/general/DmxOut	AnyTTS	'ii', base channel, value, value, value... and so on.
/beyond/general/ChannelOut	ii	
/beyond/general/OscOut	Any TTS	

From:

<http://wiki.pangolin.com/> - **Complete Help Docs**

Permanent link:

[http://wiki.pangolin.com/doku.php?id=beyond:osc\\_commands&rev=1578658703](http://wiki.pangolin.com/doku.php?id=beyond:osc_commands&rev=1578658703)Last update: **2020/06/11 19:23**