

# APC Mini MKII support

QuickShow 5.2 includes support for the USB/MIDI-based console called the APC Mini MK2 made by Akai.

Unlike other MIDI devices used by QuickShow, the APC Mini MKII will be detected when QuickShow starts, with no intervention or configuration needed by the user. Simply plug it in and start QuickShow.

## **Button and slider mapping**

Below you will see a few pictures that illustrate how the APC Mini MKII buttons and sliders are “mapped” to the QuickShow user interface.

**PANGOLIN LASER SYSTEMS** **APCmini**

**Cue Grid**

**Zone toggle**

- SOFT KEYS
  - CLIP STOP
  - SOLID
  - MUTE
  - REC ARM
  - SELECT
  - OPRM
  - MCLE
  - STOP ALL CLIPS
- SCENE LAUNCH
  - SHIFT

Blackout  
 Enable/Disable output  
 Next tab  
 Previous tab  
 Reset rotatoins  
 Reset master / cue  
 Live to master / cue  
 BPM Tap  
 Shift

Color  
 Brightness  
 Rotation X Delta  
 Rotation Y Delta  
 Rotation Z Delta  
 Size XY  
 Visible points  
 Scan speed  
 Animation speed

**AKAI PROFESSIONAL** **APCmini**

**FX Grid**

- SOFT KEYS
  - CLIP STOP
  - SOLID
  - MUTE
  - REC ARM
  - SELECT
  - OPRM
  - MCLE
  - STOP ALL CLIPS
- SCENE LAUNCH
  - SHIFT

Pause  
 Next category  
 Previous category  
 Vitual LJ Toggle  
 Set BPM 120  
 While holding shift

**Lasershow Designer QuickShow**

**WWW.PANGOLIN.COM**

See Also

- [MIDI Settings](#)

[Return to index](#)

From:

<https://wiki.pangolin.com/> - **Complete Help Docs**

Permanent link:

[https://wiki.pangolin.com/doku.php?id=quickshow:apcmini\\_mkii](https://wiki.pangolin.com/doku.php?id=quickshow:apcmini_mkii)

Last update: **2023/01/20 20:38**

