


Live Control tab - Position and Rotation controls

Using the Live Control tab, you can affect the position, rotation angle and rotation speed of everything together (when in [Master mode](#)), or of individual cues (when in [Cue mode](#)). The picture below explains the various options.



Keyboard Equivalent for Invert Rotation Speed

You can invert the rotation speed by pressing “~” (shifted or unshifted tilde key - right below the ESC key). This can be a handy tool to use while a show is playing. For example, you can set the **Z Rotation Speed** to 45, and then tap the “~” key to the beat of the music to invert the direction of the rotation each beat.

Right click

Note that if you click the right mouse button on the **Position** control or any of the **Rotation** dials, its value will be reset to 0.

See Also

- [Live Control tab](#)

- [Controlling cues during playback](#)

[Return to Index](#)

From:
<https://wiki.pangolin.com/> - **Complete Help Docs**

Permanent link:
https://wiki.pangolin.com/doku.php?id=quickshow:position_and_rotation_controls

Last update: **2020/06/11 19:20**

